



Disassembling PlayStation 2 Top Cover

Tools used in this guide


- [Metal Spudger](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Phillips #1 Screwdriver](#) (1)

Prerequisite for the lens cleaning and laser replacement.



Step 1 - Top Cover

- Flip the PlayStation 2 so that the bottom of the device is facing up.
- Using a metal spudger, pry the 8 flat screw covers out.
- Remove the following 8 screws:
 - Four 55.4 mm Philips screws.
 - Four 18 mm Phillips screws.



Step 2

- Peel the warranty sticker next to the main power switch from the case.



Step 3

- Flip the PlayStation 2 back over and remove the top cover, prying the half closer to the power switch first and rocking the whole thing towards the front.
- Carefully remove the cord that attaches the two halves by unclipping the power cord assembly from the case in the lid.



To reassemble your device, follow these instructions in reverse order.

This document was last generated on Dec 14, 2010.